

## 9575: SMS location (new message or quick GPS)

How to send your location via SMS

1. Press side convenience key
2. View location
3. Share location:
  - New message - enables you to add text and address to new contact.
  - Quick GPS - send to a preconfigured list of contacts.
4. Message sent via SMS and standard rates apply



From: [881631569984@msg.iridium.com](mailto:881631569984@msg.iridium.com) [mailto:[881631569984@msg.iridium.com](mailto:881631569984@msg.iridium.com)]  
Sent: Thursday, June 09, 2011 11:23 PM  
To: Josh Miner  
Subject: SMS from [881631569984@msg.iridium.com](mailto:881631569984@msg.iridium.com)  
Lat+39.049916 Lon-77.345783 Alt +88 m (2s ago) 10-Jun-2011 03:22:03 UTC <http://map.iridium.com/m?lat=38.923925&lon=-77.222884> iridium office

Message format:

- Link to Google map on Iridium.com included in the message (see next page)
- Text entered in by the user appears in message (e.g. iridium office)

# 9575: SMS location (new message or quick GPS)

- Link to Google map on Iridium.com
  - <http://map.iridium.com/m?lat=38.923925&lon=-77.222884>

(Standard View)



(Zoom In View)



- Option to program “Regular Updates” on scheduled interval